

EE/CS 52 Digital Oscilloscope Documentation

Julian Panetta


TA: Gabe Cohn

Table of Contents

- User's manual
- Functional Specification
- Block Diagram
- Protoboard Schematic
- Board Layout
- Timing Diagrams
 - VRAM
 - Timing Specifications
 - Read, Write, Refresh, Data Transfer
 - LCD
 - Timing Specifications
 - LCD Signals
 - SRAM
 - Read, Write
 - Rom
 - Read
- Memory Map
- Pin Assignment
- Quartus Design
 - Top Level Design
 - Analog Control Block
 - LCD/VRAM Control Block
 - LCD Signal Generator
 - Keypad Debouncer
 - Clock Divider
- VHDL
 - VRAM Controller State Machine
 - State machine diagram
 - vram_controller_lut.vhd
 - split.vhd, combine.vhd, combine_16_16.vhd
- Software
 - Drivers/Initialization
 - start.s
 - keypad.s, display.s, interrupts.s
 - constants.s
 - OS
 - stubfuncs.c
 - interfac.h

Digital Oscilloscope

User's Manual




Introduction


This digital oscilloscope is an easy-to-use instrument for visualizing analog input signals. In fact, such great care has been taken to ensure ease of use that the user's task of finding and attaching an analog voltage signal source has been removed entirely. Simply attach the oscilloscope to a computer, open up your \$2500+ copy of Quartus, program the FPGA design into it, and you're ready to view the beautiful, noise-free built-in simulated signal. Even better, there is no need to try to figure out how switch to another input signal because this oscilloscope has been specialized to display only this signal!

Hardware

The hardware devices you use to interact with and monitor the oscilloscope are described on the next page.

| Device Name | Device Type | Description |
|-------------|----------------------|--|
| Keypad | 4*4 Array of 16 keys | Of the 16 keys, only 5 are used:  |
| Display | LCD Panel | A “high” quality LCD to display the oscilloscope’s output. |
| Status LED | LED | A shiny red LED that lights when system has booted to let you know that initialization has completed successfully and the scope interface should be running. |

User Interface



Once programmed, the system boots into Normal mode with a 100ns sampling rate and a positive slope mid-level (2.480V) trigger with no delay. x- and y-axes are displayed behind the trace, and a menu in the upper right-hand corner—demonstrated in the screenshot above—lets you change all of the scope’s settings and enter different sampling modes. To hide and show the menu, press the <Menu> key.

You can change from one highlighted menu item to the next using the <Up> and <Down> keys. To alter the highlighted configuration setting, the user presses the <Left> and <Right> keys to select a value.

The configurable settings and their values are as follows:

| Menu Title | Options and Description | |
|------------|--|---|
| Mode | Normal | Scope waits for a trigger after completing each retrace. |
| | Automatic | Scope waits for a trigger after each retrace, but retriggers automatically without a trigger event after a delay. |
| | One-Shot | Scope triggers only once, continuing to display the last trace captured. |
| Scale | Scale Axes | Display x and y axes along with trace. |
| | Scale Grid | Display x-y grid along with the trace. |
| | Scale Off | Display the trace only. |
| Sweep | Items are time quantities that specify the sweep rate, or the time between successive samples options: 100ns, 200ns, 500ns, 1us, 2us, 5us, 10us, 20us, 50us, 100us, 200us, 500us, 1ms, 2ms, 5ms, 10ms, 20ms | |
| Level | 128 voltage quantities are given as choices for the trigger voltage level. The levels are equally spaced from 0V to 5V. | |
| Slope | Slope + | Scope is triggered on a positive slope (rising edge) |
| | Slope - | Scope is triggered on a negative slope (falling edge) |
| Delay | Time quantities ranging between 0ms and 1ms specify the time between the trigger and the start of the trace. | |

Limitations


If for some reason you have decided to go through the effort of finding a voltage source you want to measure, you will find that the oscilloscope has no connector to which you can attach the signal. The oscilloscope is compatible only with the built-in demonstration trace.

Digital Oscilloscope

Functional Specification

Description: The system is an interactive digital oscilloscope displaying on a 640 x 200 LCD panel. The signal is input via an analog line in, which runs through an analog to digital converter. There is a keypad to change the operation parameters. The system must be connected to a computer to program the FPGA, but can be disconnected once booted.

Inputs: Input is received through a keypad, a serial connection, and an analog input signal.

| Input Name | Input Type | Description |
|------------|----------------------|--|
| Keypad | 4*4 Array of 16 keys | Of the 16 keys, only 5 are used by the OS:  |
| Serial | RS-232 Port | Allows communication with the NIOS using GERMS. Downloading of sample data to the oscilloscope from the computer is not yet implemented. |
| Analog | Analog Line In | Analog signal line whose voltage variation with time the scope measures. This portion of the oscilloscope is not yet implemented. |

Outputs: Output is implemented with a display, a serial connection, and a LED.

| Output Name | Output Type | Description |
|-------------|-------------|---|
| Display | LCD Panel | A 640 x 200 graphics panel used to display the analog input and to present an operation and configuration menu to the user. |
| Serial | RS-232 Port | Allows sampled data to be uploaded to a |

| | | |
|------------|-----|--|
| | | computer via a serial connection. This feature is not yet implemented. |
| Status LED | LED | LED lights when system has booted to inform user that the software initialization has completed successfully and the OS should be running. |

User Interface: By default, the system boots into Normal mode with a 100ns sampling rate and a positive slope mid-level (2.480V) trigger with no delay. x- and y-axes are displayed behind the trace, and a menu in the upper right-hand corner lets the user change all of the scope's settings and enter different sampling modes. The user can press the menu key to toggle the menu's visibility.

The user changes from one highlighted menu item to the next using the up and down keys. To alter the highlighted configuration setting, the user presses the left and right keys to select a value.


Serial transfers will be implemented with "silent linking." The computer will send a request to transmit data or a request to receive data, and the oscilloscope will comply without asking the user to confirm. A status message for the transfer will be displayed in the lower left-hand corner.


The menu options are as follows:

| Menu Title | Options and Description | |
|------------|--|---|
| Mode | Normal | Scope waits for a trigger after completing each retrace. |
| | Automatic | Scope waits for a trigger after each retrace, but retriggers automatically without a trigger event after a delay. |
| | One-Shot | Scope triggers only once, continuing to display the last trace captured. |
| Scale | Scale Axes | Display x and y axes along with trace. |
| | Scale Grid | Display x-y grid along with the trace. |
| | Scale Off | Display the trace only. |
| Sweep | Items are time quantities that specify the sweep rate, or the time between successive samples options: 100ns, 200ns, 500ns, 1us, 2us, 5us, 10us, 20us, 50us, 100us, 200us, 500us, 1ms, 2ms, 5ms, 10ms, 20ms | |
| Level | 128 voltage quantities are given as choices for the trigger voltage level. The levels are equally spaced from 0V to 5V. | |
| Slope | Slope + | Scope is triggered on a positive slope (rising edge) |
| | Slope - | Scope is triggered on a negative slope (falling edge) |
| Delay | Time quantities ranging between 0ms and 1ms specify the time between the trigger and the start of the trace. | |

- Error Handling: If a key not mapped to an interface action in the current mode of operation is pressed, then no operation occurs. No other errors are anticipated for the current implementation.
Once analog and serial input is implemented, the following error handling will apply:
 If a buffer overflow occurs on the signal input queue, “Signal Buffer Overflow” is displayed in the lower left-hand corner, and no further input is accepted. If a serial overflow occurs, “Serial Buffer Overflow” is displayed. If an error with framing, parity, a break, or some other serial error occurs, the messages “Framing Error”, “Parity Error”, “Break Error”, and “Serial Error” are displayed respectively.
- Algorithms: A FFT may be implemented in the future for data analysis purposes. Currently no FFT is used.
A look up table is used to validate the user’s keypresses.
- Data Structures: A circular queue will be used to buffer serial input in case bytes are received faster than the NIOS can respond. A FIFO will also be used to buffer the signal input from the analog to digital converter/analog control block.
- Limitations: There is currently no analog or serial input.

EE/CS 52 Digital Oscilloscope Block Diagram





Timing Diagrams

- VRAM
 - Timing Specifications
 - Read, Write, Refresh, Data Transfer
- LCD
 - Timing Specifications (1180F, 1190)
 - LCD Signals
- SRAM
 - Read, Write
- Rom
 - Read

| VRAM Timing Specifications | | | |
|--|------------------|-------|------|
| DESCRIPTION | SYMBOL | MIN | MAX |
| Column address hold time after $\overline{\text{RAS}}$ low | t_{AR} | 80ns | |
| Column address setup time | t_{ASC} | 0ns | |
| Row address setup time | t_{ASR} | 0ns | |
| Access time from $\overline{\text{CAS}}$ | t_{CAC} | | 60ns |
| Column address hold time | t_{CAH} | 20ns | |
| $\overline{\text{CAS}}$ pulse width | t_{CAS} | 60ns | |
| $\overline{\text{DT}}$ low hold time after $\overline{\text{RAS}}$ low | t_{CDH} | 40ns | |
| $\overline{\text{CAS}}$ before $\overline{\text{RAS}}$ refresh hold time | t_{CHR} | 25ns | |
| $\overline{\text{CAS}}$ precharge time (page cycle only) | t_{CP} | 50ns | |
| $\overline{\text{CAS}}$ precharge time (nonpage cycle) | t_{CPN} | 25ns | |
| $\overline{\text{CAS}}$ high to $\overline{\text{RAS}}$ low precharge time | t_{CRP} | 10ns | |
| $\overline{\text{CAS}}$ hold time | t_{CSH} | 120ns | |
| $\overline{\text{CAS}}$ before $\overline{\text{RAS}}$ refresh setup time | t_{CSR} | 10ns | |
| $\overline{\text{CAS}}$ to $\overline{\text{WE}}$ delay | t_{CWD} | 100ns | |
| Write command to $\overline{\text{CAS}}$ lead time | t_{CWL} | 40ns | |
| Data-in hold time | t_{DH} | 35ns | |
| $\overline{\text{DT}}$ high hold time | t_{DHH} | 20ns | |
| Data-in hold time after $\overline{\text{RAS}}$ low | t_{DHR} | 95ns | |
| $\overline{\text{DT}}$ high setup time | t_{DHS} | 0 | |


| VRAM Timing Specifications continued... | | | |
|--|-----------|-------|---------|
| DESCRIPTION | SYMBOL | MIN | MAX |
| \overline{DT} low setup time | t_{DLS} | 0 | |
| Data-in setup time | t_{DS} | 0 | |
| \overline{DT} high to \overline{CAS} high delay | t_{DTC} | 10ns | |
| \overline{DT} high hold time after \overline{RAS} high | t_{DTH} | 20ns | |
| \overline{DT} high to \overline{RAS} high delay | t_{DTR} | 10ns | |
| \overline{OE} pulse width | t_{OE} | 35ns | |
| Access time from \overline{OE} | t_{OEA} | | 30ns |
| \overline{OE} to data-in setup delay | t_{OED} | 35ns | |
| \overline{OE} hold time after \overline{WE} low | t_{OEH} | 30ns | |
| \overline{OE} to \overline{RAS} inactive setup time | t_{OES} | 10ns | |
| Output disable time from \overline{OE} high | t_{OEZ} | 0 | 30ns |
| Output disable time from \overline{CAS} high | t_{OFF} | 0 | 30ns |
| Page cycle time | t_{PC} | 120ns | |
| Access time from \overline{RAS} | t_{RAC} | | 120ns |
| Row address hold time | t_{RAH} | 15ns | |
| \overline{RAS} pulse width | t_{RAS} | 120ns | 10000ns |
| Random read or write cycle time | t_{RC} | 220ns | |
| \overline{RAS} to \overline{CAS} delay time | t_{RCD} | 25ns | 60ns |
| Read command hold time after \overline{CAS} high | t_{RCH} | 0 | |

| VRAM Timing Specifications continued... | | | |
|---|-----------|-------|---------|
| DESCRIPTION | SYMBOL | MIN | MAX |
| Read command setup time | t_{RCS} | 0 | |
| \overline{DT} low hold time after \overline{RAS} low (serial port active) | t_{RDH} | 100ns | |
| Refresh interval | t_{REF} | | 4ns |
| \overline{RAS} precharge time | t_{RP} | 90ns | |
| \overline{RAS} high to \overline{CAS} low precharge time | t_{RPC} | 0 | |
| Read command hold after \overline{RAS} high | t_{RRH} | 20ns | |
| \overline{RAS} hold time | t_{RSH} | 60ns | |
| Read-write/read-modify-write cycle time | t_{RWC} | 300ns | |
| \overline{RAS} to \overline{WE} delay | t_{RWD} | 160ns | |
| to be defined | t | | |
| Write command to \overline{RAS} lead time | t_{RWL} | 40ns | |
| SC pulse width | t_{SCH} | 10ns | |
| Serial output access time from SC | t_{SCA} | | 40ns |
| Serial clock cycle time | t_{SCC} | 40ns | 50000ns |
| SC precharge time | t_{SCL} | 10ns | |
| SC high to \overline{DT} high delay | t_{SDD} | 10ns | |
| SC low hold time after \overline{DT} high | t_{SDH} | 10ns | |
| Serial output access time from \overline{SOE} | t_{SOA} | | 35ns |
| \overline{SOE} pulse width | t_{SOE} | 15ns | |

| VRAM Timing Specifications continued... | | | |
|---|-------------------|------|------|
| DESCRIPTION | SYMBOL | MIN | MAX |
| Serial output hold time after SC high | t_{SOH} | 10ns | |
| \overline{SOE} low to serial output setup delay | t_{SOO} | 5ns | |
| \overline{SOE} precharge time | t_{SOP} | 15ns | |
| Serial output disable time from \overline{SOE} high | t_{SOZ} | 0 | 30ns |
| Rise and fall transition time | t_T | 3ns | 50ns |
| Write-per-bit hold time | t_{WBH} | 20ns | |
| Write-per-bit setup time | t_{WBS} | 0 | |
| Write command hold time | t_{WCH} | 35ns | |
| Write command hold time after \overline{RAS} low | t_{WCR} | 95ns | |
| Write command setup time | t_{WCS} | 0 | |
| Write bit selection hold time | t_{WH} | 20ns | |
| Write command pulse width | t_{WP} | 35ns | |
| Write bit selection setup time | t_{WS} | 0 | |
| Actual \overline{RAS} to \overline{CAS} delay | t_{RCD_Actual} | 100 | 100 |




vram_write




vram_refresh

Page 1



VRAM Data Transfer



| 1180F | | | | |
|------------|------------|--------------------------------|------|-----|
| SYMBOL | DEFINITION | DESCRIPTION | MIN | MAX |
| t_{CLC} | | shift clock cycle | 166 | |
| t_{WCLH} | | Shift clock "H" width | 63 | |
| t_{WCLL} | | Shift clock "L" width | 63 | |
| t_{DS} | | Data setup time | 50 | |
| t_{DH} | | Data hold time | 30 | |
| t_{WECH} | | Enable clock "H" width | 100 | |
| t_{WECL} | | Enable clock "L" width | 100 | |
| t_{EDS} | | Enable data setup time | 50 | |
| t_{EDH} | | Enable data hold time | 20 | |
| t_{EDR} | | Enable clock delay time | -10 | |
| t_{ECS} | | Enable clock setup time | 70 | |
| t_{WLPH} | | Latch pulse "H" width | 110 | |
| t_{WLPL} | | Latch pulse "L" width | 220 | |
| t_{LT} | | Latch timing | 100 | |
| t_{LH} | | Latch hold time | 0 | |
| t_{LDS} | | Latch pulse data setup time | 140 | |
| t_{LDH} | | Latch pulse data hold time | 50 | |
| t_{DFR} | | Permissible frame signal delay | -500 | 500 |

1180F continued...

| SYMBOL | DEFINITION | DESCRIPTION | MIN | MAX | NOTES |
|----------|------------|---------------------|-----|-----|-------|
| t_{PD} | | Enable output delay | 20 | 150 | |




1190


| SYMBOL | DEFINITION | DESCRIPTION | MIN | MAX | NOTES |
|------------|--------------------------------|---------------|------|-----|-------|
| t_{CYL} | Latch pulse cycle time | to be defined | 400 | | |
| t_{WLTH} | Latch pulse "H" width | to be defined | 180 | | |
| t_{WLL} | Latch pulse "L" width | to be defined | 180 | | |
| t_{CYC} | Shift clock cycle time | to be defined | 400 | | |
| t_{WCLH} | Shift clock "H" time | to be defined | 110 | | |
| t_{WCLL} | Shift clock "L" time | to be defined | 240 | | |
| t_{DS} | Data setup time | to be defined | 70 | | |
| t_{DH} | Data hold time | to be defined | 30 | | |
| t_{ST} | Data shift timing | to be defined | 0 | | |
| t_{STH} | Data shift hold time | to be defined | 125 | | |
| t_{DFR} | Permissible frame signal delay | to be defined | -500 | 500 | |
| t_{pD} | Data output delay time | to be defined | 30 | 170 | |




LCD Timing

Page 1






SRAM Write



ROM Read

Page 1



Memory Map

| | | | | | |
|--|-------------------------------------|-----|------------|------------|----|
| ⊕ rom_0 | ROM | | 0x00000000 | 0x0007FFFF | |
| ⊕ ram_0 | RAM | | 0x00080000 | 0x00087FFF | |
| ⊕ onchip_memory_0 | Legacy On-Chip Memory (RAM or R... | clk | 0x00088000 | 0x000887FF | |
| ⊕ uart_0 | UART (RS-232 serial port) | clk | 0x00088800 | 0x0008881F | 16 |
| ⊕ keydata_pio | PIO (Parallel I/O) | clk | 0x00088820 | 0x0008882F | |
| ⊕ key_ready_pio | PIO (Parallel I/O) | clk | 0x00088830 | 0x0008883F | 17 |
| ⊕ analog_control_settings_data_pio | PIO (Parallel I/O) | clk | 0x00088840 | 0x0008884F | |
| ⊕ analog_control_settings_selector_... | PIO (Parallel I/O) | clk | 0x00088850 | 0x0008885F | |
| ⊕ analog_control_reset_pio | PIO (Parallel I/O) | clk | 0x00088860 | 0x0008886F | |
| ⊕ analog_fifo_read_req_pio | PIO (Parallel I/O) | clk | 0x00088870 | 0x0008887F | |
| ⊕ analog_fifo_data_in_pio | PIO (Parallel I/O) | clk | 0x00088880 | 0x0008888F | |
| ⊕ analog_fifo_full_pio | PIO (Parallel I/O) | clk | 0x00088890 | 0x0008889F | 18 |
| ⊕ analog_fifo_empty_pio | PIO (Parallel I/O) | clk | 0x000888A0 | 0x000888AF | 19 |
| ⊕ LED_pio | PIO (Parallel I/O) | clk | 0x000888B0 | 0x000888BF | |
| ⊕ vram_0 | VRAM | | 0x00090000 | 0x0009FFFF | |
| ⊕ tri_state_bridge_0 | Avalon Tri-State Bridge | clk | | | |
| ⊕ nios_0 | Nios Processor - Altera Corporation | clk | | | |

Digital Oscilloscope APEX20K Pin Assignments

| To | Location | General Function | Special Function |
|----------|----------|------------------|------------------|
| CLOCK | PIN_27 | Dedicated Clock | CLK1 |
| RESET | PIN_142 | Row I/O | nRS |
| U4OE1 | PIN_187 | Column I/O | |
| U4OE2 | PIN_206 | Column I/O | |
| U6OE1 | PIN_57 | Column I/O | |
| U6OE2 | PIN_84 | Column I/O | |
| U6DIR2 | PIN_85 | Column I/O | |
| U7DIR1 | PIN_87 | Column I/O | |
| U7DIR2 | PIN_108 | Row I/O | |
| U7OE1 | PIN_88 | Column I/O | |
| U7OE2 | PIN_107 | Row I/O | |
| U8DIR1 | PIN_2 | Row I/O | |
| U8DIR2 | PIN_31 | Row I/O | |
| U8OE1 | PIN_5 | Row I/O | |
| U8OE2 | PIN_30 | Row I/O | |
| U9DIR1 | PIN_32 | Row I/O | |
| U9DIR2 | PIN_55 | Column I/O | |
| U9OE1 | PIN_33 | Row I/O | |
| U9OE2 | PIN_54 | Column I/O | |
| U10OE1 | PIN_112 | Row I/O | |
| U10OE2 | PIN_158 | Column I/O | |
| addr[0] | PIN_71 | Column I/O | |
| addr[1] | PIN_72 | Column I/O | |
| addr[2] | PIN_73 | Column I/O | |
| addr[3] | PIN_74 | Column I/O | |
| addr[4] | PIN_89 | Column I/O | |
| addr[5] | PIN_90 | Column I/O | |
| addr[6] | PIN_91 | Column I/O | |
| addr[7] | PIN_92 | Column I/O | |
| addr[8] | PIN_93 | Column I/O | |
| addr[9] | PIN_94 | Column I/O | |
| addr[10] | PIN_96 | Column I/O | |
| addr[11] | PIN_97 | Column I/O | |
| addr[12] | PIN_98 | Column I/O | |
| addr[13] | PIN_99 | Column I/O | |
| addr[14] | PIN_100 | Column I/O | |
| addr[15] | PIN_101 | Column I/O | |
| addr[16] | PIN_102 | Column I/O | |
| addr[17] | PIN_103 | Column I/O | |
| addr[18] | PIN_104 | Column I/O | |
| data[0] | PIN_58 | Column I/O | |
| data[1] | PIN_59 | Column I/O | |
| data[2] | PIN_60 | Column I/O | |
| data[3] | PIN_61 | Column I/O | |
| data[4] | PIN_62 | Column I/O | |
| data[5] | PIN_63 | Column I/O | |
| data[6] | PIN_65 | Column I/O | |

Digital Oscilloscope APEX20K Pin Assignments

| | | | |
|-------------|---------|------------|--|
| data[7] | PIN_66 | Column I/O | |
| nCS_RAM | PIN_37 | Row I/O | |
| nCS_ROM | PIN_34 | Row I/O | |
| nRD | PIN_67 | Column I/O | |
| nWR | PIN_68 | Column I/O | |
| U6DIR1 | PIN_56 | Column I/O | |
| TX1 | PIN_17 | Row I/O | |
| RX2 | PIN_7 | Row I/O | |
| keypad_row | PIN_120 | Row I/O | |
| keypad_row | PIN_122 | Row I/O | |
| keypad_row | PIN_123 | Row I/O | |
| keypad_row | PIN_134 | Row I/O | |
| keypad_col | PIN_140 | Row I/O | |
| keypad_col | PIN_144 | Row I/O | |
| keypad_col | PIN_151 | Row I/O | |
| keypad_col | PIN_152 | Row I/O | |
| U10DIR1 | PIN_111 | Row I/O | |
| U10DIR2 | PIN_161 | Column I/O | |
| STATUS_LE | PIN_117 | Row I/O | |
| U4DIR1 | PIN_179 | Column I/O | |
| U4DIR2 | PIN_207 | Column I/O | |
| vaddr[0] | PIN_44 | Row I/O | |
| vaddr[1] | PIN_204 | Column I/O | |
| vaddr[2] | PIN_203 | Column I/O | |
| vaddr[3] | PIN_202 | Column I/O | |
| vaddr[4] | PIN_201 | Column I/O | |
| vaddr[5] | PIN_200 | Column I/O | |
| vaddr[6] | PIN_198 | Column I/O | |
| vaddr[7] | PIN_197 | Column I/O | |
| vdata[0] | PIN_193 | Column I/O | |
| vdata[1] | PIN_194 | Column I/O | |
| vdata[2] | PIN_195 | Column I/O | |
| vdata[3] | PIN_196 | Column I/O | |
| nRAS | PIN_45 | Row I/O | |
| nCAS | PIN_46 | Row I/O | |
| nDTCOE | PIN_49 | Row I/O | |
| nWBWE | PIN_50 | Row I/O | |
| VRAM_SC | PIN_51 | Row I/O | |
| DI | PIN_38 | Row I/O | |
| DisplayEnal | PIN_40 | Row I/O | |
| FR | PIN_41 | Row I/O | |
| LP | PIN_113 | Row I/O | |
| ECL | PIN_115 | Row I/O | |
| YSCL | PIN_42 | Row I/O | |


Quartus Design

- Top Level Design
- Analog Control Block
- LCD/VRAM Control Block
- LCD Signal Generator
- Keypad Debouncer
- Clock Divider

Date: November , 2008

oscilloscope.bdf


Project: oscilloscope





LCD/VRAM Block


Implements reads, writes, data transfers, and refreshes for the VRAM using a finite state machine implemented in VHDL. Generates the signals needed to drive the LCD using a block design file with counters and comparators.



LCD Signal Generator
Generates the timing signals to be sent to the LCD
and the row address used during a VRAM Data Transfer
See the LCD timing diagram for the timings that this
design implements.

Inputs:

nRS - Active low reset signal
clk - System clock, assumed to be 20MHz
Signal to clear (reset) components
System clock (20MHz)




This design file implements a keypad debouncer. The implementation debounces a keypress for 20ms and repeats a key every subsequent 300ms if the user continues to hold it.

The debouncer supports multiple keypresses on a single row, but does not respond to simultaneous keypresses occurring on different rows. In this case, the first row with a keypress encountered during row multiplexing is the only one from which keypresses are debounced.

When a key is debounced, key_ready will pulse high for 1ms, and the encoded presses can be read from key_data[6..0].


This debouncer assumes that the clock runs at 20MHz. If it doesn't, the debounce and key repeat times will differ from the stated values.



Clock Divider

Divides clk_in by scale_factor , generating a new clock on clk_out .


Known issues: if scale_factor is odd, the divided clock cycle will occur in $(\text{scale_factor} - 1)$ ticks (rounds down to nearest even integer). A scale_factor of 1 is not allowed, as it will cause an overflow in the computation of $(\text{scale_factor} / 2) - 1$.



VHDL

- VRAM Controller State Machine
 - State machine diagram
 - vram_controller_lut.vhd
- Miscellaneous Helper Blocks
 - split.vhd
 - combine.vhd
 - combine_16_16.vhd

Actions executed upon state entry.



```

-----
--
-- Oscilloscope VRAM Controller
--
-- This VHDL file implements a controller for the NEC uPD41264-12 VRAM chip.
-- The controller is implemented using a state machine whose transitions are
-- a function of the input lines. Output signals change upon transition to
-- a new state, and their values are looked up in a table indexed by current
-- state number.
--
-- The controller uses a wait request line to halt the NIOS cpu until it is
-- able to complete a read or write, since a refresh cycle or data transfer
-- cycle could delay read/write cycles an amount unpredictable to the Avalon
-- Tristate Bus.
--
-- See the state diagram for a visual overview of the state machine.
-- Inputs and outputs are enumerated and described in the port section below.
--
-- Revision History:
--      10/23/08      Julian Panetta   Initial Revision
--      11/16/08      Julian Panetta   Reformatted to fit within 80 chracters wide
--
-----

```

```

Library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;
use ieee.numeric_std.all;

entity vram_controller_lut is
    port (
        -- 16-bit address input (row & column addresses) with 3 disregarded
        -- most significant bits so it interfaces with 19-bit shared Avalon bus
        addr      :    in std_logic_vector(18 downto 0);

        -- 8-bit data bus (data / writemask nibbles)
        data      :    inout std_logic_vector(7 downto 0);

        -- Write enable
        nWR       :    in std_logic;

        -- Output enable
        nRD       :    in std_logic;

        -- System clock (Assumed to be 20MHz)
        clk       :    in std_logic;

        -- Chip select
        nCS       :    in std_logic;

        -- Data transfer needs to occur before a new cycle can be completed.
        -- ('1' == true, '0' == false)
        DT_SOON   :    in std_logic;

        -- Data transfer needs to occur NOW
        -- ('1' == true, '0' == false)
        DT_NOW    :    in std_logic;

        -- reset state machine to known, IDLE state
        nRS       :    in std_logic;

        -- Row address to be used for the data transfer cycle.
        -- (The data transfer column is always 0.)
        DT_ROW    :    in std_logic_vector(7 downto 0);
    );
end entity vram_controller_lut;

```

```

-- 4-bit data bus to VRAM
vdata    :    inout std_logic_vector(3 downto 0);

-- 8-bit address bus out to VRAM
vaddr    :    out std_logic_vector(7 downto 0);

-- CAS signal to VRAM
nCAS     :    out std_logic;

-- RAS signal to VRAM
nRAS     :    out std_logic;

-- nWB/nWE signal to VRAM
nWBWE    :    out std_logic;

-- nDT/nOE signal to VRAM
nDTOE    :    out std_logic;

-- Wait request signal for NIOS
WR       :    out std_logic
);
end vram_controller_lut;

architecture Moore_machine of vram_controller_lut is
    constant IDLE           :    integer range 0 to 23 := 0;
    -- VRAM Read Cycle States
    constant READ_ONE       :    integer range 0 to 23 := 1;
    constant READ_TWO       :    integer range 0 to 23 := 2;
    constant READ_THREE     :    integer range 0 to 23 := 3;
    constant READ_FOUR      :    integer range 0 to 23 := 4;
    constant READ_FIVE      :    integer range 0 to 23 := 5;
    constant READ_SIX       :    integer range 0 to 23 := 6;
    -- VRAM Write Cycle States
    constant WRITE_ONE      :    integer range 0 to 23 := 7;
    constant WRITE_TWO      :    integer range 0 to 23 := 8;
    constant WRITE_THREE    :    integer range 0 to 23 := 9;
    constant WRITE_FOUR     :    integer range 0 to 23 := 10;
    constant WRITE_FIVE     :    integer range 0 to 23 := 11;
    constant WRITE_SIX      :    integer range 0 to 23 := 12;
    -- VRAM Refresh Cycle States
    constant REFRESH_ONE    :    integer range 0 to 23 := 13;
    constant REFRESH_TWO    :    integer range 0 to 23 := 14;
    constant REFRESH_THREE  :    integer range 0 to 23 := 15;
    constant REFRESH_FOUR   :    integer range 0 to 23 := 16;
    constant REFRESH_FIVE   :    integer range 0 to 23 := 17;
    -- VRAM Data Transfer Cycle States
    constant DTRAN_ONE      :    integer range 0 to 23 := 18;
    constant DTRAN_TWO      :    integer range 0 to 23 := 19;
    constant DTRAN_THREE    :    integer range 0 to 23 := 20;
    constant DTRAN_FOUR     :    integer range 0 to 23 := 21;
    constant DTRAN_FIVE     :    integer range 0 to 23 := 22;
    constant DTRAN_SIX      :    integer range 0 to 23 := 23;

    -- LUT for control line ouputs. 0 => nRAS, 1 => nCAS, 2 => nWBWE, 3 => nDTOE, 4 =>
    WR
    type TABLE is array(0 to 23) of std_logic_vector(4 downto 0);
    constant OUTPUT_BITS :    TABLE := (
        -- IDLE control line values
        "11111",

        -- READ_* control line values
        "11111", "11110", "11110", "10100", "00100", "11111",

```



```

-- WRITE_* control line values
"11011", "11010", "11010", "11000", "11000", "01111",

-- REFRESH_* control line values
"11101", "11100", "11100", "11100", "11111",

-- DTRAN_* control line values
"10111", "10110", "10110", "10100", "11100", "11111");

signal    CurrentState    :    integer range 0 to 23;    -- current state
signal    NextState       :    integer range 0 to 23;    -- next state
begin
-- Compute the next state (function of current state and inputs) using
-- concurrent statements
NextState <=
-- Transitions to IDLE
IDLE      when    (nRS = '0')
else IDLE      when    (CurrentState = READ_SIX or
CurrentState = WRITE_SIX or CurrentState = REFRESH_FIVE or
CurrentState = DTRAN_SIX)

-- Idle State transitions
else READ_ONE  when    (CurrentState = IDLE and nRD = '0' and
DT_SOON = '0' and nCS = '0')
else WRITE_ONE when    (CurrentState = IDLE and nWR = '0' and
DT_SOON = '0' and nCS = '0')
else REFRESH_ONE when    (CurrentState = IDLE and nCS = '1' and
DT_SOON = '0')
else DTRAN_ONE  when    (CurrentState = IDLE and DT_NOW = '1')
else IDLE      when    (CurrentState = IDLE)
-- Movement Within Cycles
else    CurrentState + 1;

-- Upon transition into the new state, update the control line values
-- using the output lookup table.
output_computation : process (CurrentState)
begin
-- Look up and set control line values for the current state
nRAS    <= OUTPUT_BITS(CurrentState)(0);
nCAS    <= OUTPUT_BITS(CurrentState)(1);
nWBWE   <= OUTPUT_BITS(CurrentState)(2);
nDTOE   <= OUTPUT_BITS(CurrentState)(3);
WR       <= OUTPUT_BITS(CurrentState)(4);

-- VRAM address line access
-- Assert row address for the first and second read and write states.
if (CurrentState = READ_ONE or CurrentState = WRITE_ONE or
CurrentState = READ_TWO or CurrentState = WRITE_TWO) then
vaddr    <= addr(15 downto 8);
else
-- Assert col address for the third/fourth read and write states.
if (CurrentState = READ_THREE or CurrentState = READ_FOUR or
CurrentState = WRITE_THREE or CurrentState = WRITE_FOUR) then
vaddr    <= addr(7 downto 0);
else
-- Assert DT row address for the first and second DT states.
if (CurrentState = DTRAN_ONE or CurrentState = DTRAN_TWO) then
vaddr    <= DT_ROW;
else
-- Output zero address in all other states.
vaddr    <= "00000000";
end if;
end if;
end if;
end if;

```

```

-- VRAM data bus access
-- Transfer VRAM data to Avalon Bus for the fifth read state.
if (CurrentState = READ_FIVE) then
    data    <= "0000" & vdata;
else
    -- Assert write mask for the first and second write state.
    if (CurrentState = WRITE_ONE or CurrentState = WRITE_TWO) then
        vdata    <= data(7 downto 4);
    else
        -- Assert graphics nibble for the third and fourth write state.
        if (CurrentState = WRITE_THREE or
            CurrentState = WRITE_FOUR) then
            vdata    <= data(3 downto 0);
        else
            -- In all other states, the Avalon data bus and the VRAM
            -- data bus should be high impedance.
            vdata <= "ZZZZ";
            data  <= "ZZZZZZZZ";
        end if;
    end if;
end if;

end process output_computation;

-- Make actual transition to the new state on rising clock edge
make_transition : process (clk)
begin
    if clk = '1' then          -- Only change on the rising clock edge
        CurrentState <= NextState;    -- Transition to the new state
    end if;
end process;

end Moore_machine;

```

```
-----
--
-- Split
--
-- Splits the 16-bit input bits read from port a evenly into the 8 LSBs (placed
-- on "low" output line) and the 8 MSBs (placed on "high" output line).
--
-- Revision History:
--      09/05/08      Julian Panetta   Initial Revision
-----

Library ieee;
use ieee.std_logic_1164.all;

entity split is
    port (
        a      : in  std_logic_vector(15 downto 0);
        low    : out std_logic_vector(7  downto 0);
        high   : out std_logic_vector(7  downto 0)
    );
end split;

architecture dataflow of split is
begin
    low <= a(7 downto 0);
    high <= a(15 downto 8);
end dataflow;
```

```
-----  
--  
-- Combine  
--  
-- (For use with computing debounced keypress output)  
-- Concatenates 2-bit row address read from port a with 4-bit column data read  
-- from port b into a 6-bit output placed on port c. The row address is placed  
-- in the MSBs of the output and the column address is placed in the LSBs.  
--  
-----  
Library ieee;  
use ieee.std_logic_1164.all;  
  
entity combine is  
    port  
        a      : in  std_logic_vector(1 downto 0);  
        b      : in  std_logic_vector(3 downto 0);  
        c      : out std_logic_vector(5 downto 0)  
    ;  
end combine;  
  
architecture dataflow of combine is  
begin  
    c <= a & b;  
end dataflow;
```

```
-----  
--  
-- Combine 16_16  
--  
-- Concatenates two 16-bit inputs (read from ports a and b) into a 32-bit  
-- output value placed on port c. the value of port a is placed in the most  
-- significant bits of c, and b's value is placed in the least significant  
-- bits.  
--  
-- Revision History:  
--      09/05/08      Julian Panetta   Initial Revision  
-----
```

```
Library ieee;  
use ieee.std_logic_1164.all;  
  
entity combine_16_16 is  
    port  
        a      : in  std_logic_vector(15 downto 0);  
        b      : in  std_logic_vector(15 downto 0);  
        c      : out std_logic_vector(31 downto 0)  
    ;  
end combine_16_16;  
  
architecture dataflow of combine_16_16 is  
begin  
    c <= a & b;  
end dataflow;
```

Software

- Drivers/Initialization (NIOS Assembly)
 - start.s
 - Initializes hardware and calls oscilloscope operating system main loop.
 - Global symbols: _start
 - keypad.s
 - Interrupt-driven driver for the keypad
 - Global symbols: install_key_handler, getkey, key_available
 - display.s
 - Code for drawing on and clearing the LCD
 - Global symbols: plot_pixel, clear_display
 - interrupts.s
 - Code for initializing interrupts
 - Global symbols: init_interrupts
 - constants.s
 - Include file holding constants used throughout the NIOS assembly files listed above.
- OS (C)
 - stubfuncs.c
 - Functions emulating hardware not yet implemented
 - Global symbols: set_sample_rate, set_trigger, set_delay, start_sample, sample_done
 - interfac.h
 - Include file holding constants used throughout the oscilloscope operating system.

```

;::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
; File: start.s
; Description:
;   Code run when the NIOS resets. Performs hardware initialization and then
;   branches to Glen George's oscilloscope code.
;
; Input:      Keypresses from the user, analog signal input (not implemented)
; Output:     Output displayed
;
; Known Bugs:  None
; Revision History:
;   11/04/08    Julian Panetta  Initial Revision
;   11/17/08    Julian Panetta  Added more extensive documentation
;::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
.include "excalibur.s"
.include "constants.s"

.text
.global _start

;::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
; void _start(void)
;::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
; Description:
;   Code located at the NIOS' reset location. Initializes hardware and then
;   runs the oscilloscope OS.
; Operation:
;   - Installs the keypad handler, initialize_interrupts, and forces interrupts
;     to be enabled.
;   - Turns on the status LED.
;   - Branches to the oscilloscope's main loop from which the NIOs should never
;     return.
;
; Arguments:  None
; Return Values:  None
;
; Inputs:     Keypresses read from keypad
; Outputs:    User interface displayed on LCD
;
; Registers Destroyed:  None (Registers SAVED, no supervisor/caller anyway).
; Shared Variables:  None
;
; Data Structures/Algorithms:  None
;::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::::
_start:
    SAVE    %sp, 0        ; No stack space is needed

    _BSR    install_key_handler
    NOP

    _BSR    init_interrupts
    NOP

; Turn on interrupts
; According to the NIOS Programmer's Manual, interrupts should be enabled
; by default and need only be enabled if explicitly disabled previously.
; However, I have found the interrupts don't function if they aren't
; enabled as done by the following two lines. These lines were copied
; verbatim from the Programmer's Manual.
    PFX     9
    WRCTL   %g0

; Turn on the LED to indicate the system has booted
    MOVI    %11, LED_ON

```

```
MOVIA    %l0, na_LED_pio
PFX      np_piodata
ST       [%l0], %l1

_BSR     main      ; Run Glen's oscilloscope code
NOP

; This line should never be reached.
RESTRET
```



```

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; File: keypad.s
; Description:
;     Routines to allow Glen George's oscilloscope software interface with
;     the debounced keypad.
; Input:     Debounced keypresses from the user (ISR run when keypress made).
; Output:     None.
;
; Known Bugs:    None
; Revision History:
;     09/06/08    Julian Panetta    Initial Revision
;     11/17/08    Julian Panetta    Added documentation and replaced
;                                     magic numbers with constants.
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
#include "excalibur.s"
#include "constants.s"

.data
key_ready:  .4byte  false
key_data:   .4byte  KEY_ILLEGAL

.text
.global install_key_handler
.global getkey
.global key_available

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; void install_key_handler(void)
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Description:
;     Installs and initializes the isr that is run when a key is debounced.
; Operation:
;     - Intalls ISR.
;     - Clears key_ready and key_data variables.
;     - Clears edge capture register so previous keypresses aren't detected.
;
; Arguments: None
; Return Values: None
;
; Outputs: None
; Registers Destroyed: None (Registers SAVED/RESTORED)
;
; Shared Variables:
;     key_ready    -- (Cleared) Boolean value recording the occurrence of a keypress
;     key_data     -- (Cleared) Byte recording the value of the keypress
;
; Data Structures/Algorithms: None
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
install_key_handler:
    SAVE    %sp, 0    ; no stack space is needed

    MOVIA   %o0, na_key_ready_pio_irq    ; select key_ready interrupt
    MOVIA   %o1, key_handler@h           ; load ISR address
    MOVIA   %o2, 0                       ; context (ignored)

    BSR     nr_installuserisr            ; install our keypad isr
    NOP

    ; Initialize key_ready and key_data words to zero
    MOVIA   %l2, false

    MOVIA   %l1, key_ready
    ST      [%l1], %l2                    ; No key is ready initially

```

```

MOVIA    %12, KEY_ILLEGAL          ; (Not needed as false == KEY_ILLEGAL)
MOVIA    %11, key_data             ; No valid key is encoded initially
ST       [%11], %12

; Clear the edge capture register to ensure a keypress made
; before loading the code doesn't result in an interrupt.
MOVIA    %11, na_key_ready_pio
MOVI     %10, false
PFX      np_pioedgecapture
ST       [%11], %10

RESTRET

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; void key_handler(void)
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Description:
;   ISR that is run when a key is pressed. Simply records the presence of a key
;   and resets the interrupt event.
; Operation:
;   - Clears the edge capture register so the event doesn't fire until a new
;     keypress is made.
;   - Sets key_ready and stores debounced key data in key_data.
;
; Arguments: None
; Return Values: None
;
; Inputs:   Keys pressed by the user trigger this handler
; Outputs:  None
;
; Registers Destroyed: None (Registers SAVED/RESTORED)
; Shared Variables:
;   key_ready  -- (Set) Boolean value recording the occurrence of a keypress
;   key_data   -- (Stored) Byte recording the value of the keypress
;
; Data Structures/Algorithms: None
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
key_handler:
    SAVE    %sp, 0                ; no stack space is needed
    ; clear the edge capture register
    MOVIA    %11, na_key_ready_pio
    MOVI     %10, 0
    PFX      np_pioedgecapture
    ST       [%11], %10

    MOVIA    %10, key_ready
    MOVI     %r0, true
    ST8S     [%10], %r0, 0        ; Indicate a debounced key was received

    MOVIA    %10, na_keydata_pio
    PFX      np_piodata
    LD       %11, [%10]

    MOVIA    %10, key_data
    ST       [%10], %11

    RESTORE
    TRET     %o7

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; unsigned char key_available(void)
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Description:
;   Returns 0x01 if a key press is ready for reading and 0x00 if not.

```

```

; Operation:
;   - Reads key_ready and extracts bit 1 as the return value.
;
; Arguments: None
; Return Values: None
;
; Inputs: None
; Outputs: None
;
; Registers Destroyed: None (Registers SAVED/RESTORED)
; Shared Variables:
;   key_ready  -- (Read) Boolean value recording the occurrence of a keypress
;
; Data Structures/Algorithms: None
;
key_available:
    SAVE    %sp, 0          ; No stack space is needed
    MOVIA   %o1, key_ready
    LD      %o0, [%o1]
    MOVI    %o1, true

    AND     %o0, %o1        ; Check if a keypress is ready
    RESTRET

;
;
; int getKey(void)
;
; Description:
;   Waits until a valid keypress is made (if one hasn't been already) and then
;   returns that keypress' code.
; Operation:
;   - Waits until a a keypress has been made.
;   - Performs a lookup to see if that key is valid.
;   - Returns the key if it is valid, otherwise waits for another keypress.
;
; Arguments: None
; Return Values: None
;
; Inputs: Valid keys pressed by the user are returned by this routine.
; Outputs: None
;
; Registers Destroyed: None (Registers SAVED/RESTORED)
; Shared Variables: None
;   key_ready  -- (Read) Boolean value recording the occurrence of a keypress
;   key_data   -- (Read) Byte recording the value of the keypress
;
; Data Structures/Algorithms: Look up table is used to validate keypresses
;
getKey:
    SAVE    %sp, 0          ; no stack space is needed

    MOVIA   %l0, key_ready
    MOVIA   %l3, key_data
    MOVI    %l2, true

wait:
    LD      %l1, [%l0]
    AND     %l1, %l2        ; Check key is ready

    IFS     cc_z
    BR      wait            ; wait until a key is ready
    NOP

    MOVI    %l1, false
    ST      [%l0], %l1      ; clear key ready

```

```

        LD      %i0, [%13]      ; get key_data
        EXT8D   %i0, %11       ; put key_data in low byte of return value

        MOVIA   %14, valid_keys
validate_loop:
        LD      %15, [%14]

        CMP     %i0, %15
        IFS     cc_eq           ; valid key?
        BR      valid          ; return it.
        NOP

        CMPI    %15, KEY_ILLEGAL
        IFS     cc_eq           ; invalid key?
        BR      wait           ; wait for a valid one.
        NOP

        BR      validate_loop   ; not sure yet!
        ADDI    %14, 1          ; move to the next key entry

valid:
        RESTRET

; //////////////////////////////////////
; valid_keys:
; //////////////////////////////////////
; Description:
;   Constant table of valid keypress values terminated by KEY_ILLEGAL.
; //////////////////////////////////////
valid_keys:
        .word   KEY_UP
        .word   KEY_DOWN
        .word   KEY_LEFT
        .word   KEY_RIGHT
        .word   KEY_MENU
        .word   KEY_ILLEGAL ; KEY_ILLEGAL Terminates the list of valid keys

```

```

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; File: display.s
; Description:
;     Routines to set individual pixels on the LCD and clear the entire LCD.
; Input:      None.
; Output:     Pixels displayed on LCD.
;
; Known Bugs:  None
; Revision History:
;     11/04/08    Julian Panetta    Initial Revision
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
#include "excalibur.s"
#include "constants.s"

.text
.global plot_pixel
.global clear_display

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; void plot_pixel(unsigned int x, unsigned int y, int p)
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Description:
;     Sets the pixel at the passed (x, y) to the value p.
;     The origin of the screen coordinate system is the upper left corner.
; Operation:
;     - Computes the VRAM address of the nibble holding the desired pixel.
;     - Adds this offset to the VRAM base address to compute the absolute address.
;     - Creates a bit mask for the VRAM write so that only the desired pixel of
;       the nibble is modified.
;     - Sets the write data to all 1's for p == PIXEL_BLACK and all 0's for
;       p == PIXEL_WHITE. This ensures the selected pixel is set to the correct
;       value, regardless of which of the four pixels it is.
;     - Sends these computed write mask and data nibbles to the VRAM
;
; Arguments (After execution of SAVE):
;     %i0 = x coordinate of desired pixel
;     %i1 = y coordinate of desired pixel
;     %i2 = p = color to paint specified pixel
;
; Return Values: None
;
; Outputs: Pixel at (x, y) painted with color p.
;          (Corresponding bit in VRAM is set)
;
; Registers Destroyed: None (Registers SAVED/RESTORED)
; Stack depth: 0
;
; Shared Variables: None
;
; Data Structures/Algorithms: None
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
plot_pixel:
    SAVE    %sp, 0 ; no stack space is required

    ; Load VRAM base address
    MOVIA   %i0, na_vram_0

    ; Compute offset from VRAM base address:
    ; Offset = (VRAM_row << 8) + VRAM_column
    ;          = (y << 8) + (x >> 2)

    LSLI    %i1, 8 ; move y coordinate into the row portion of offset
    ADD     %i0, %i1

```

```

MOV    %l1, %i0    ; Get a copy of the x coordinate
LSR    %l1, 2      ; get the nibble in which the pixel appears

ADD    %l0, %l1    ; Add in the column portion of the nibble offset

MOVI   %l2, 3
AND    %i0, %l2    ; get the x offset within that nibble

BGEN   %l1, 7      ; set the leftmost pixel enable bit
LSR    %l1, %i0    ; shift the pixel enable bit into the 'x' location
                        ; within the write mask

; If the color, p, is PIXEL_WHITE, set all the bits in the graphics nibble
; to '0' (to clear the pixel). Otherwise, set all the bits in the graphics
; nibble to '1' (blacken the pixel). Assuming the PIXEL_WHITE value is 0
; and the PIXEL_BLACK value is 0x0F, p can simply be Ored into the data
; byte.
OR     %l1, %i2

FILL8  %r0, %l1    ; Fill all bytes of this word with the computed
                        ; graphics byte so ST8D will read it in all cases

ST8D   [%l0], %r0

RESTRET

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; void clear_display(void)
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Description:
;   Sets all the LCD pixels to white.
; Operation:
;   Iterates over the portions of VRAM mapped to pixels on the LCD, and paints
;   them all white 16 pixels (4 nibbles) at a time.
;
; Arguments: None
; Return Values: None

; Outputs: All pixels on the LCD are painted white.
;           (All bits in VRAM that are displayed on the LCD are set to '0')
;
; Registers Destroyed: None
; Stack depth: 0
; Shared Variables: None
; Data Structures/Algorithms: None
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
clear_display:
    SAVE    %sp, 0                ; no stack space is required

    ; Load VRAM base address
    MOVIA   %l0, na_vram_0
    MOVIA   %l3, CLEAR_PATTERN    ; Load pattern to clear 4 graphics nibbles

    MOVIA   %l1, SIZE_Y            ; loop over all LCD rows
    MOVIA   %l4, ROW_ADVANCE      ; Ammount added to address to advance row
row_loop:
    MOVIA   %l2, LCD_NIBBLES_WIDE ; loop over all the nibbles in the row

col_loop:
    ST      [%l0], %l3            ; Clear 4 nibbles (16 pixels) of the LCD

    SUBI    %l2, NIBBLES_PER_WRITE ; Subtract nibbles cleared from remaining
    IFS     cc_nz
    BR      col_loop              ; Continue until there are none remaining

```

```
    ADDI    %10, COLUMN_ADVANCE    ; Move to the next set of 4 nibbles

    SUBI    %11, ROWS_PER_LOOP     ; Subtract rows cleared from rows remaining
    IFS     cc_nz
    BR      row_loop               ; Continue until there are no rows remaining
    ADD     %10, %14               ; Advance to the start of the next row

    RESTRET
```

```

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; File: interrupts.s
; Description:
;     Routine to enable interrupts for the NIOS CPU.
;     The only interrupts acknowledged are from the keypad, so
;     only the na_key_ready_pio's interrupt need be enabled.
; Input:      None.
; Output:     None.
;
; Known Bugs:  None
;
; Revision History:
;     09/06/08    Julian Panetta    Initial Revision
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
#include "excalibur.s"

.text
.global init_interrupts

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; void init_interrupts(void)
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Description:
;     Enables all the interrupts to be acknowledged by the NIOS.
;     This should only be called AFTER the ISRs to handle these interrupts have
;     already been installed.
; Operation:
;     - Sets the key_ready pio's interrupt mask bit to '1' so that the debounced
;       key bit line can interrupt the NIOS' operation.
;
; Arguments:  None
; Return Values:  None
; Outputs:  None
; Registers Destroyed:  None (Registers SAVED/RESTORED)
; Stack depth:  0
; Shared Variables:  None
; Data Structures/Algorithms:  None
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
init_interrupts:
    SAVE    %sp, 0 ; No stack space is needed

    MOVIA   %l0, na_key_ready_pio
    MOVI    %l1, 1
    STP [%l0, np_piointerruptmask], %l1

    RESTRET

```



```

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; File: constants.s
; Description:
;   Defines constants used by the keypad and display hardware drivers.
;   Also defines global software constants and constants related to the status
;   LED.
;
; Revision History:
;   11/17/08   Julian Panetta   Initial Revision
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Global Constants
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
.equ true,    1      ; Boolean true value
.equ false,   0      ; Boolean false value

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Status LED Constants
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
.equ LED_ON,   1      ; Value to write to LED PIO to turn on Status LED
.equ LED_OFF,  0      ; Value to write to LED PIO to turn off Status LED

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Display Constants
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
.equ PIXEL_BLACK,    0X0F      ; Pixel color passed to draw black pixels.
.equ PIXEL_WHITE,    0X00      ; Pixel color passed to draw white pixels.
.equ CLEAR_PATTERN,  0xF0F0F0F0 ; Word value that will clear 16 bits of VRAM

; VRAM/LCD Properties
.equ SIZE_X,        640      ; X resolution of the LCD
.equ SIZE_Y,        200      ; Y resolution of the LCD
.equ LCD_NIBBLES_WIDE, (SIZE_X / 4); Number of nibbles in VRAM per LCD row
.equ VRAM_WIDTH,    256      ; Number of nibbles in VRAM per VRAM row

; Constants used for clearing the LCD efficiently
.equ NIBBLES_PER_WRITE, 4      ; Number of nibbles cleared per write
.equ COLUMN_ADVANCE,    NIBBLES_PER_WRITE ; Number of nibbles to skip over to
                                           ; advance to the next column
.equ ROWS_PER_LOOP,     1      ; Number of rows cleared per iteration
.equ ROW_ADVANCE,       (VRAM_WIDTH - LCD_NIBBLES_WIDE) ; Number of nibbles to skip
                                           ; to advance to the next row

;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
; Keypad Constants
;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;;
.equ KEY_UP,          0x02      ; <Up>
.equ KEY_DOWN,         0x22      ; <Down>
.equ KEY_LEFT,         0x11      ; <Left>
.equ KEY_RIGHT,        0x14      ; <Right>
.equ KEY_MENU,         0x12      ; <Menu>
.equ KEY_ILLEGAL,      0x00      ; Illegal Key

```

```

/*****
/*
/*          STUBFNCS
/*      Oscilloscope Stub Functions
/*      Digital Oscilloscope Project
/*          EE/CS 52
/*
*****/

/*
This file contains stub functions for the hardware interfacing code for the
Digital Oscilloscope project.  The file is meant to allow linking of the
main code without necessarily having all of the low-level functions or
hardware working.  The functions included are:
    key_available    - check if a key is available
    getkey           - get a key
    clear_display    - clear the display
    plot_pixel       - plot a pixel
    set_sample_rate  - set the sample rate
    set_trigger      - set the trigger level and slope
    set_delay        - set the trigger delay
    start_sample     - start sampling
    sample_done      - sampling status

The local functions included are:
    none

The locally global variable definitions included are:
    none

Revision History
    3/8/94   Glen George   Initial revision.
    3/13/94  Glen George   Updated comments.
    3/13/94  Glen George   Changed set_sample_rate to return SIZE_X.
    5/9/06   Glen George   Updated start_sample stub to match the new
                           specification.
    11/4/08  Julian Panetta Altered stub functions to implement test
                           analog sample. Also removed stub functions
                           for keypad/display which have real
                           implmeentations.
*/

/* library include files */
/* none */

/* local include files */
#include "interfac.h"
#include "scopedef.h"

/* Variables used to store state of analog hardware simulator */
static long int sample_rate;
static int sample_level, sample_slope;
static long int sample_delay;
static int is_sampling;

/* Buffer to store simulated analog input data */
static char sample_data[SIZE_X];

/* sampling parameter functions */

int set_sample_rate(long int rate)

```

```
{
    sample_rate = rate;
    return SIZE_X;
}

void set_trigger(int level, int slope)
{
    sample_level = level;
    sample_slope = slope;
    return;
}

void set_delay(long int delay)
{
    sample_delay = delay;
    return;
}

/* sampling functions */

void start_sample(int auto_trigger)
{
    get_test_sample(sample_rate, SIZE_X, sample_data);
    is_sampling = 1;
}

unsigned char far *sample_done()
{
    /* Only return NULL once per sample */
    if (!is_sampling)
        return NULL;
    else {
        is_sampling = 0;
        return sample_data;
    }
}
```

```

/*****
/*
/*          INTERFAC.H          */
/*      Interface Definitions    */
/*      Include File            */
/*      Digital Oscilloscope Project */
/*          EE/CS 52             */
/*
*****/

/*
This file contains the constants for interfacing between the C code and
the assembly code/hardware for the Digital Oscilloscope project.  This is
a sample interface file to allow compilation of the .c files.

Revision History:
    3/8/94   Glen George      Initial revision.
    3/13/94  Glen George      Updated comments.
    3/17/97  Glen George      Added constant MAX_SAMPLE_SIZE and removed
                              KEY_UNUSED.
    11/04/08 Julian Panetta    Updated to match constants of my hardware
                              drivers.
*/

#ifndef __INTERFAC_H__
#define __INTERFAC_H__

/* library include files */
/* none */

/* local include files */
/* none */

/* constants */

/* keypad constants */
#define KEY_MENU      0x12      /* <Menu>      */
#define KEY_UP        0x02      /* <Up>         */
#define KEY_DOWN      0x22      /* <Down>       */
#define KEY_LEFT      0x11      /* <Left>       */
#define KEY_RIGHT     0x14      /* <Right>      */
#define KEY_ILLEGAL   0        /* illegal key */

/* display constants */
#define SIZE_X         640      /* size in the x dimension */
#define SIZE_Y         200      /* size in the y dimension */
#define PIXEL_WHITE    0        /* pixel off */
#define PIXEL_BLACK    0xF      /* pixel on */

/* scope parameters */
#define MIN_DELAY      0        /* minimum trigger delay */
#define MAX_DELAY      50000     /* maximum trigger delay */
#define MIN_LEVEL      0        /* minimum trigger level (in mV) */
#define MAX_LEVEL      5000     /* maximum trigger level (in mV) */

/* sampling parameters */
#define MAX_SAMPLE_SIZE 2400    /* maximum size of a sample (in samples) */

#endif

```